

Installation of Obie Link Guard to BETA 4-Stroke Stock or Hyde Plastic & Aluminum Skid Plates



First, slide the Obie Link Guard in between the skid plate and the frame (with the engraved side up on the right side of the bike and the curled-up end by the shock). It may be necessary to grind the holes out on your skid plate (as the arrow shows) so that the mounting holes in your skid plate will line up with the mounting tabs on the frame. Always mount the Obie Link Guard between the frame and your skid plate for a smooth transition from skid plate to link guard.



For further mounting instructions go to www.obielinkguard.com and check out our installation instruction video or call Mark "Obie" (208) 949-7299

"Protection is Good"