



Kickstand Pad

Part# AB-10204

2013 + All Models (minus 125 RR-S)

Installation Instructions:

Please wear proper eye protection when installing this kit

1. Place kickstand pad onto the bottom of the side stand & mark the hole with a center punch.
2. Drill a hole approx. 1" (25mm) deep with the drill bit provided in the kit.
3. Tap the threads of the hole with the tap provided & clean debris out of the hole.
4. Place kickstand pad onto the side stand, install a small amount of thread locking agent onto the mounting screw.
5. Affix the kickstand pad by tightening the countersunk screw provided in the kit.

