



Steering Lock Plug

Part# AB-20015/AB-20015-20

fits RR, RS, RR-S, RX (Except 125) and XTrainer

Installation Instructions:

1. Lightly tap the lock retaining rivet head with a chisel or sharp flathead screwdriver from both sides to slightly raise the rivet head, being careful not to break it off.
2. Use a vice grip to firmly grab the rivet head, then twist it counter clockwise to unthread the rivet from the frame.
3. Insert the key into the lock & turn to the left, then pull the lock assembly out of the frame including the spring.
4. Apply silicone to the O-ring area & fully insert the plug into the lock location. Turn the plug until it's vertically aligned.

