



Bullet Proof Designs  
100 SE 30<sup>th</sup> Street  
Lee's Summit, MO 64082  
(816) 695-3784  
[www.bulletproofdesigns.com](http://www.bulletproofdesigns.com)

## Beta X-Trainer Radiator Guard Installation

### Mounting:

1. Remove radiator shrouds
2. Remove existing radiator guards
3. Remove the (2) radiator mounting screws, these will be re-used
4. Slide guard in place (guard might be tight but should snap in place). Outside mounting holes should line up with existing clearance holes for plastic shrouds. Use M6x16 BHCS (button heads) for these holes
5. Install top inside mounting bolts with a ratcheting wrench or standard box wrench. Use stock bolt with AND 6MM washer
6. Install lower inside mounting through clearance hole in guard (8mm T-handle or socket with extension) Use stock bolt with 6MM washers.
7. Tighten all bolts. Do not over tighten.
8. Turn steering to check fork tube clearance.
9. Re-install side panels and seat

*Note: These guards are designs and built for precision fit to maintain radiator integrity. If the radiators are already bent the guards my not fit correctly.*

