



Bullet Proof Designs
100 SE 30th Street
Lee's Summit, MO 64082
(816) 695-3784
www.bulletproofdesigns.com

Beta Swingarm Guard Installation

Note: Customer may choose to install the BPD Swingarm guard without drilling any holes in the swingarm. For extreme use, adding mounting holes to the swingarm will increase strength.

Mounting (without drilling)

1. Remove stock bolts from chain guide
2. Install guard using a M6x55mm bolt (Must remove lower inside chain cover or get a M6X60mm bolt) and M6x25mm bolt.

Mounting guard to swingarm (optional) But highly recommended!

3. Slide chain guide forward on chain, out of way
4. Bolt Swingarm guard in place using a M6x55mm and M6x25mm bolts. Use supplied Spacer (Stock chain guide .375 thick), or the longer one (.5 thick) if running TM (TM Designs) on back of guard to space it per picture.
5. Using #9 drill bit, drill holes in swingarm using the holes in the guard as a guide
6. Tap holes using a M6 X1.00 tap
7. Mount guard to swingarm using supplied M6 SHCS (Socket Head Chrome Screws)
8. Push chain guide into place and bolt up using supplied hardware

