



Meter Guard

Part# AB-21172

Fits: 2017+ RR 2-Stroke & 4-Stroke,
& 2017+ X-Trainer

Installation Instructions:

1. Detach headlight mask by disconnecting rubber fork straps from fork, lift mask upward & outward to expose wiring.
 2. Disconnect the headlight wire harness single bullet connector, & the white plastic 3-pin connector by pressing down on its locking tab (shown at left).
 3. To disconnect the meter's 16-pin connector, gently pull on the small red locking tab (shown at left) until it clicks, then pull off the rectangular 16-pin connector from the meter.
 4. Remove trip meter from its plastic mounting bracket by unscrewing both phillips mounting screws, along with their round aluminum bushings.
 5. Separate the Beta meter guard faceplate from its body by unscrewing its four, 2mm hex screws, then insert meter into the meter guard.
 6. Install meter & guard onto the mounting bracket using both round bushings & the 2 longer phillips screws included with the guard, then reinstall the faceplate.
1. Reconnect the 16-pin harness, push in the small red locking tab, then reconnect both headlight connectors.
 2. Re-install headlight mask onto the two front fender tabs, re-attach rubber mounting straps, & check that the meter & headlight both function correctly.

