



# Beta Airbox Cover Fastener Kit

Part# AB-22002

Fits: All Beta's with quick-release airbox covers

## Installation Instructions:

**Tools Needed:** Power drill, 1/8" & 7/32" drill-bits, vise-grip pliers or a bench-vise, exacto knife, heat source, 3mm allen wrench.

1. Using a 1/8" drill bit, drill out all 4 rivets that hold the 2 metal airbox attachment clips in the stock airbox.
2. Push the 4 rivets outwards from the inside of the airbox & remove both attachment clips, Fig. 1.
3. Using the 4 supplied screws, install the new T-brackets snugly, with the T-bracket's flat sides facing outwards, Fig. 2.
4. Using a bench-vise or vise-grips, clamp each mounting stud & turn the airbox cover in order to loosen them. Each stud has 2 deep retaining grooves & they're molded into the cover, which makes removal difficult.
5. It's optional to use an exacto knife to cut a groove down the side of the stud's plastic mount-grommet in order to open the plastic slightly & extract the stud. Heating the blade makes this easier, Fig. 3.
6. To ensure the airbox cover seals tightly against the airbox, also trim approx. 3/8" plastic off the top of the stud's plastic mounting grommet, making it approx. 3/8" shorter, Fig. 4.
7. Drill out both stud mounting holes using a 7/32" drill bit. Drill through the airbox cover from the inside out, through the center of both stud mounts, for the new attachment screw holes, Fig. 5.
8. Install the new mounting screws & aluminum grommets in the airbox cover. Re-install the airbox cover, checking for proper cover alignment & that all screws are securely tightened.

