



Acerbis Fork Shoe Guard

Part# AB-22020 & AB-22021

Fits: AB-22020 12-18 RR/RR-S AB-22021 19+ RR/RR-S

Installation Instructions:



1. Remove axle pinch bolts, put to the side for reuse in the future



2. Apply fork shoe guard with proper spacers & bolts included in the kit.



3. Tighten to proper torque specs listed in your owners manual.



4. Once you have torqued the bolts you are ready to ride with your new fork shoe guards!